



UK Custom Covers[®]
Custom Designs For Ultimate Protection

BB676UKCC

FORD TRANSIT MK8 VAN / TIPPER / LEADER (2014-2020)

FULL BONNET BRA - 676

IMPORTANT:

Prior to fitting please ensure the bonnet bra is at room temperature (at least 24 degrees) for 12 hours. Failure to do so could cause damage to the bonnet bra. UK Custom Covers are unable to take responsibility for any damage caused to the bonnet bra if these fitting instructions are not followed.

Open the bonnet hood and fit the bonnet bra corners first (As pictured to the right)



Now thread the cord through each of the elastic loops following the edge of the bonnet bra (As pictured to the right). You may like to use the Full length of cord to go round twice, or you can Cut off the excess. Once threaded through all Of the loops – pull tight and tie together in a knot.

