



UK Custom Covers

Custom Designs For Ultimate Protection

Fitting Instructions QBL630UKCC

Audi A6 Avant - 2018 Onwards

IMPORTANT PREPARATION NOTES

Before attaching the self adhesive velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

Part 1 - Main Liner

- Before Installing the Boot liner please lay the liner out on a clean surface with the shiny side up, on the liner you will see Velcro segments, using the Velcro provided please cut to the relevant sizes as seen on the boot liner. Velcro is only required on the leading edge of the boot liner, the sides of the boot liner attach directly to the carpet area of the boot.
- Apply the Velcro tabs that you have previously cut to the corresponding Velcro strips that are sewn on the boot liner, leaving the backing of the self-adhesive Velcro on the strips that have been cut.
- Place the boot liner in the boot area of the vehicle, please ensure the liner is placed shiny side down. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.
- Place the side panels in position, Attach the sides directly to the carpet area using the Velcro sewn onto the liner, push the pockets of the boot liner into the recesses on each side if applicable. At the tailgate end using the liner as a guide peel off the backing of the Velcro and attach directly to the vehicle.

Part 2 – Removeable Bumper Flap

- Match the hook Velcro on the bumper flap to the loop Velcro sewn at the tailgate end of the liner.

Part 3 – Tailgate Cover

- Please cut the supplied Velcro to the relevant sizes as seen on the back of the tailgate cover, using the tailgate cover as a guide attach the tailgate cover directly to the vehicle.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD

Velcro Fixing Kit – 108 Inches, please cut Velcro supplied to the relevant sizes.