



**UK Custom Covers**<sup>®</sup>  
Custom Designs For Ultimate Protection

## Screen Curtain Blind

**SB829UKCC**

**Mercedes Sprinter (2006-2018) / VW Crafter (2006-2017)**

Fit as per below:



Tools Required: Phillips Screwdriver, Electric Drill, 2.5mm Drill Bit

Prior to fitting the windscreen curtain you will need to fit three poppers to each of the front 'A' pillar trims. The poppers need to be positioned at each end of the groove that runs down the middle of the trim (Pictured to the left)



Driver's and Passenger's Door Curtains: Place the curtain up to the door and attach the magnets that are built into the curtain to the metalwork surrounding the window. You can make adjustments for the best fit and tuck the curtain in at the bottom.

