



## Fitting Instructions 092

Audi

Q3 Standard Floor 2011 - 2018

### IMPORTANT PREPARATION NOTES

Before attaching the self adhesive velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

### THE BASE OF THE SEATS SHOULD BE IN THE REAR POSITION

1. Remove the load cover cassette
2. Take the liner out of its carry case and place in the vehicle so that the base fits neatly into position. The panel with the UK Custom Covers label attached sits against the back of the rear seat.
3. Attached to the front of the liner are Velcro straps, align these to the headrest locator poles.
4. Pass the tapes around each headrest locator pole and Velcro back onto themselves.
5. Carefully position the side panels neatly into place, the velcro sewn onto the sides of the liner will attach directly to the carpet.
6. At the tailgate end of the liner, attach 2 x 14 inch strips of velcro to the velcro sewn onto the liner, using the liner as a guide, remove the backing tape and fix to the vehicle.
7. To position the bumper flap in the upright position, attach the velcro supplied to the velcro tabs sewn onto the bumper flap, remove the velcro backing and using the liner as a guide, attach these in the gutters of the tailgate.

**PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD**

Velcro Fixing Kit – 2 x 14 inch plus 2 x 4 inch for bumper flap

(1 x36 Inch velcro strip supplied, please cut to length as required)